



Frosted Window Graphics - Suggested Application Instructions

Please Note

Printed Frosted Window Graphics are always applied to the **outside** of the window. Plotter Cut Frosted Window Graphics (without any printing) are almost always applied to the **inside** of the window.

Step 1

Before applying the window graphics, always ensure that the window has been thoroughly cleaned. Once the window has been cleaned, thoroughly wet the glass. We recommend using a spray bottle containing water with a few drops of washing up liquid. Applying to wet glass means that you can reposition your graphic more easily to make sure it's in the correct position.

Step 2

Place the graphic on a hard flat surface with the application tape on the top. Smooth down the application tape across the entire graphic using our recommended squeegee (or a credit card wrapped in a paper towel) to make sure it is firmly attached to the frosted vinyl underneath.

Step 3

Lift up a corner of the application tape and begin to slowly peel it back. The application tape needs to lift the frosted window graphic off the white backing paper. As you lift the graphic from the backing paper, spray the sticky side of the vinyl with water to avoid it sticking to itself. Try not to get the white backing paper wet as you do this. Continue to carefully and slowly peel back the application tape lifting the entire design from the backing paper, spraying it as you lift. You may wish to tape the backing paper down or ask someone else to hold it down for you, particularly if the design is very large.

Step 4

Once the entire frosted window graphic has been lifted, move the white backing paper out of the way and hold your graphic near the window in the position that you'd like it to be applied.

Step 5

With the frosted window graphic in the final position, carefully lower the top edge of the graphic onto the window and press the edge down. You can position the top edge of the graphic by sliding it around on the wet surface until it is in the correct position. Starting at the top-centre and working horizontally, use the squeegee to push the trapped water out at the sides as you lower the rest of the graphic onto the window.

Step 6

Once the graphic is fully applied and all excess water has been removed using the squeegee, leave the application tape on the window graphic for 24 hours. This allows the graphic to dry out and adhere fully to the window. After 24 hours have passed, carefully remove the application tape to reveal your finished frosted window graphic.

Disclaimers

Please satisfy yourself that you are confident of how to apply your graphic on to your chosen surface before attempting application. Colour Frog cannot be held responsible for a poor or failed application. Do not attempt to apply the graphics in very cold or very hot temperatures. If your product comes with gridded application tape the gridlines are not to be used as a horizontal level when applying your graphic. Always look at the graphic when ensuring it will be level as the grid squares may not be horizontally aligned with the graphic itself.